

2097/18 A1351057

EN

## RF33863

CHROME MEDIUM ARM (310mm)



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)

Flos reserves the right to introduce any changes to its own models, without prior notice.

2097/18 A1351057

EN

## RF33863

CHROME MEDIUM ARM (310mm)




Fig.1




Fig.2

Screw the arms (H) to the lamp body (I), taking care not to bend on the rings (L).  
Insert the lamp holder (M) in the ring (L) and fasten them by locking the screw (N).

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.