

2097/18 A1351031

ΕN

RF33864

OPAL BLACK MEDIUM ARM (310mm)




2097/18 A1351031

ΕN

RF33864

OPAL BLACK MEDIUM ARM (310mm)



Screw the arms (H) to the lamp body (I), taking care not to bend on the rings (L). Insert the lamp holder (M) in the ring (L) and fasten them by locking the screw (N).