

TANGO INTERIOR


last update 18/11/2014

BEL1159

BEL LIGHTING

BEL LIGHTING sprl
Avenue Ernest Solvay 42
B-1480 Saintes (Tubize)
Belgium
Phone: +32(0)2 3552428
Fax: +32(0)2 3550396
e-mail: info@bel-lighting.com
www.bel-lighting.com


Tango R V :	code: 8086V. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			
Tango R H :	code: 8086H. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			
Tango R X :	code: 8086X. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			
Tango K V :	code: 8088V. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			
Tango K H :	code: 8088H. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			
Tango K X :	code: 8088X. _ 30. _ _	3,2W/350mA - CE - IP40 - IK10 -			



INSTALLATION INSTRUCTIONS - PART A

1. PREPARATION OF TROUGHS
2. MAKE THE ELECTRICAL CONNECTION
3. PLACE THE LUMINARY
4. SWITCH ON

- 1** NL - Voorbereiding op uitholling
FR - Préparation du trou
EN - Preparation of troughs
DE - Vorbereitung des loch
GR - Προετοιμασία τρυπα



OPTIONS




POP 9




2 ELECTRICAL CONNECTION

Installation : Led Power Supply

Red : +
Black : -
only use a Power supply delivery from BEL LIGHTING - SENICO



on 350mA



PART

A

Lees de algemene gebruiksvoorwaarden : PART B
Lire attentivement les conditions générales d'utilisation: PART B
Read attentively the general instructions: PART B
Lesen Sie die allgemeinen Gebrauchsanweisungen: PART B
Diabaste thV genikeV odhgieV : PART B

WAARSCHUWING
AVERTISSEMENT
WARNING
WARNUNG
PROSOCH