

RF02179

Protection grid support



RF02179

Protection grid support




Fig.1

Insert the supports (G) in the housings (H) of the protection grid (I), ensuring that they are inserted inside properly.

RF02179

Protection grid support




Fig.2

Insert the supports (G) and the protection grid (I) in the transparent ring (E).

RF02179

Protection grid support




Fig.3

Insert the ring nut (I) and the fabric sheet (D) in the plastic diffuser housings (L) until they click into place as indicated in the figure on the left hand side.

REMARKS! For a correct installation, align the three supports with the plastic diffuser.