


IC S2


Designed by Michael Anastassiades, 2014

F3176035





ΕN



 $\textbf{01. F3137035} \ - \text{Glass diffuser S2 assembly for red burgundy version}$

02. RF3170335 – S1/S2 red burgundy ceiling rose assembly

03. RF3160100 – Kit with screws and Allen key

04. RF3160200 – E27 lamp holder assembly




ΕN

F3137035

GLASS DIFFUSER S2 ASSEMBLY FOR RED BURGUNDY VERSION





WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.



ΕN

F3137035

GLASS DIFFUSER S2 ASSEMBLY FOR RED BURGUNDY VERSION




Fig.1

Assemble the glass diffuser (E) by fastening it delicately to the lamp body's ferrule (F).




ΕN

RF3170335

S1/S2 RED BURGUNDY CEILING ROSE ASSEMBLY







WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.



ΕN

RF3170335

S1/S2 RED BURGUNDY CEILING ROSE ASSEMBLY




Fig.1

Install the wall fitting (B) to the ceiling with screws and plugs, ensuring that the

power wires pass through the hole (H). **REMARKS!!!** Choose screw plugs that are suitable for the type of mounting surface

ΕN

RF3170335

S1/S2 RED BURGUNDY CEILING ROSE ASSEMBLY




Fig.2

Assemble the ceiling rose on the ceiling attachment by fastening it with a slight clockwise rotation to then lock it by screwing the headless screws (A).




ΕN

RF3160100

KIT WITH SCREWS AND ALLEN KEY





WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.



ΕN

RF3160100

KIT WITH SCREWS AND ALLEN KEY




Fig.1

Before proceeding in installing the screws, please verify that the glass diffuser (M) has been removed. If not, please remove to the glass diffuser (M) to avoid possible damages.



ΕN

RF3160100

KIT WITH SCREWS AND ALLEN KEY




Fig.2

Assemble the ceiling rose on the ceiling attachment by fastening it with a slight clockwise rotation to then lock it by screwing the headless screws (A).

Assemble back the glass diffuser (M) by fastening it delicately to the lamp body's ferrule (N). (Fig.1 page 9)



ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY





ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY




Fig.1

Unfasten the glass diffuser (M) and lamp-bulb from the lamp fixture.

ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY




Fig.2

By utilizing a tiny flat screw driver, carefully push towards the inside, the lateral spring (A) of the lamp holder.




Fig.3

Unfasten the lamp holder sleeve (B) from the support (C).

ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY




Fig.4

Disconnect the wires from the fitting (E) electrical terminals (D).



Fig.5

Remove the fitting (E) from the support (C) and disconnect the earth wire from the terminal (F).

ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY




Fig.6




Fig.7

ΕN

RF3160200

E27 LAMP HOLDER ASSEMBLY




Fig.8

Insert the lamp bulb and fasten the glass diffuser (M) to the ferrule (N) of the lamp body.