


Rax Soft 200









220-240V~, 50/60Hz



NO: Kan kun installeres og vedlikeholdes av en registrert installasjonsvirksomhet.
DK: Må kun installeres og vedlikeholdes af uddannet elektriker.
SE: Skall installeras och underhållas av behörig elektriker.
EN: Only to be installed and maintained by an authorized electrician.
FR: Doit être installé et maintenu par un électricien qualifié.
NL: Mag alleen geïnstalleerd en onderhouden worden door een bevoegde electricien.
DE: Dieses Produkt darf nur durch autorisiertes Personal (z.B. Elektro-Installateur) angeschlossen, in Betrieb genommen und gewartet werden.
FI: Asentaa ja huoltaa saa vain valtuutettu sähköasentaja

NO: Skru av strømmen før montering.
DK: Sluk for strømmen inden montering.
SE: Stäng av strømmen innan montering.
EN: Turn off power before installing.
FR: Couper le courant avant l'installation.
NL: Stroom uitschakelen voor u het toestel installeert.
DE: Vor Installationsarbeiten den Strom abschalten.
FI: Sammuta virta ennen kytkemistä



NORWAY
SG Armaturen AS

Skytterheia 25
N-4790 Lillesand

Tel: +47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN
SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FINLAND
SG Armaturen Oy
Tel: +358 02 07 30 39 60
info@sg-oy.fi
www.sg-oy.fi

DENMARK
SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

UNITED KINGDOM
SG Lighting LTD
Tel: +47 37 50 03 00
info@sglighting.co.uk
www.sglighting.co.uk




FRANCE
SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net

BENELUX
SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net

GERMANY
SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de



INTERNATIONAL
SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com

Dipswitch




| | | | | | | | |
|---|-----------|-----|-----|-----|-------------|-------------|------|
| Rax Soft 200 Satin 1600lm | mA | 200 | 250 | 300 | 350 | 400 | 450 |
| | lm | 57% | 71% | 86% | 100% | 111% | 125% |
| Rax Soft 200 Satin Asymmetric 1600lm | mA | 200 | 250 | 300 | 350 | 400 | 450 |
| | lm | 51% | 64% | 76% | 89% | 100% | 112% |

Dipswitch



| | | | | | |
|---|-----------|-------------|-------------|-------------|-------------|
| Rax Soft 200 Satin 2200lm | mA | 500 | 600 | 700 | 800 |
| | lm | 100% | 118% | 138% | 154% |
| Rax Soft 200 Satin 3000lm | mA | 500 | 600 | 700 | 800 |
| | lm | 72% | 86% | 100% | 111% |
| Rax Soft 200 Satin Asymmetric 2200lm | mA | 500 | 600 | 700 | 800 |
| | lm | 84% | 100% | 116% | 130% |
| Rax Soft 200 Satin 2200lm Ra>90 | mA | 500 | 600 | 700 | 800 |
| | lm | 84% | 100% | 116% | 130% |
| Rax Soft 200 Satin Asymmetric 3000lm | mA | 500 | 600 | 700 | 800 |
| | lm | 65% | 77% | 90% | 100% |
| Rax Soft 200 Black 2200lm | mA | 500 | 600 | 700 | 800 |
| | lm | 84% | 100% | 116% | 130% |
| Rax Soft 200 Black 3000lm | mA | 500 | 600 | 700 | 800 |
| | lm | 65% | 78% | 90% | 100% |

Dipswitch



| | | | | | |
|------------------------------|-----------|-----|-----|-----|-------------|
| Rax Soft 200 Satin 4500lm | mA | 800 | 900 | 950 | 1050 |
| | lm | 77% | 86% | 91% | 100% |