


M-LED 50 GE

14060005 14060105 14060205 14060305 14060405 14060505 14060605 14060705 14060805 14060905 14061005 14061105

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	16,5	19,2	6,2
500	17,1	19,8	9,2


For serial connection, respect polarity!



The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person

Replace protective shield when broken. The luminaire shall only be used complete with its protective shield. Reference number: 1011481

CAN BE USED WITH Drivers:
see driver matrix - latest version on website www.supermodular.com or check sales contact



V
Volt
Volts
Volts
Volt
Voltio
Volt
Вольт
فولت

A
Ampère
Ampères
Amperes
Ampere
Amperio
Ampere
Ампер
أمبير

W
Watt
Watts
Watts
Watt
Watio
Watt
Ватт
وات

Gelijkspanning
Alimentation en courant alternatif
DC power
Gleichstrom
Corriente continua
Corrente continua
Постоянный ток
تيار متردد

Klasse 3
Classe 3
Class 3
Klasse 3
Classe 3
classe 3
Класс 3
الفئة 3

CE
Norm
Norme
Standard
Norm
Norma
Norma
Norma
Норма
قياسي

Raak de LED niet aan
Do not touch the LED
Touchez pas la LED
Berühren Sie die LED nicht
No toque el LED
Non toccare il LED
Не прикасайтесь к светодиоду
لا تلمس وحدات الإضاءة LED

Interieur gebruik
Utilisation intérieur
Innenverwendung
Interior use
Usu interior
Для использования внутри помещений
للاستخدام داخل المباني

Beschermglas vervangen indien beschadigd
Remplace le verre de protection si celui-ci est endommagé
Replace protective glass cover if damaged
Schutzglas ersetzt, wenn sie beschädigt
Sostituire el vidrio protector en caso de que esté dañado
Sostituire il vetro protettivo se danneggiato
Заменить защитное стекло в случае его повреждения
استبدل غطاء الحماية الزجاجي عند تضرره

supermodular.com

For a complete international dealer list, please contact our website: www.supermodular.com

Main office Belgium

Modular Lighting Instruments
Armoedestraat 71 • 8800 Roeselare • Belgium
t + 32 51 26 56 56 • f + 32 51 22 80 04
welcome@supermodular.com

INSTALLATIE MOET GEBEUREN DOOR EEN ERKEND INSTALLATEUR
L'INSTALLATION DOIT ETRE FAITE PAR UN INSTALLATEUR COMPETENT
INSTALLATION MUST BE DONE BY A COMPETENT INSTALLER
INSTALLATION MUSS VON EINEM KOMPETENTEN INSTALLATEUR DIRCHGEFÜHRT WERDEN
LA INSTALACION DEBE HACERLA UN INSTALADOR COMPETENTE
INSTALLAZIONE DEVE ESSERE EFFETTUATA DA UN INSTALLATORE QUALIFICATO
МОНТАЖ СВЕТИЛЬНИКА ДОЛЖЕН ВЫПОЛНЯТЬСЯ КВАЛИФИЦИРОВАННЫМ СПЕЦИАЛИСТОМ
يجب جليءة نور جءة بة سءءة نوء لة سءءةءة ءءص

MODULAR
LIGHTING —
INSTRUMENTS