

# RF6330100

Kit of n.3 diffuser bracket supports



# RF6330100

Kit of n.3 diffuser bracket supports




Fig.1

Unfasten the screws (E) from the support (C) and then lift-up the diffuser (A).

#### RF6330100

Kit of n.3 diffuser bracket supports




Fig.2

Remove the diffuser (A) from the metal stem (B).
Unfasten the "PAR" bulb from the lower lamp holder.
Remove the base (E) from the supports (F) by unfastening the three self-threading screws.

Unfasten the screw (D) and disconnect the earth wire (C).

Assemble now the new spare-part:

Connect the earth cable (C) to the base (e) by fastening the screw (D), ensuring to insert the cable between the screw and the notched washer; Assemble the base (E) to the supports (F) by fastening the three self-threading screws.

Screw the "PAR" bulb into the lower bulb-holder. Slide the diffuser (A) through the metal stem (B).

### RF6330100

Kit of n.3 diffuser bracket supports




Fig.3

Remove the support (F) by unfastening the screw (G).
Remarks!!! Utilize the metal brackets (H) for the new spare-part.
Install the support (F) with the metal bracket.

### RF6330100

Kit of n.3 diffuser bracket supports




Fig.4

Connect the earth cable (C) to the base by fastening the screw (D), ensuring to insert the cable between the screw and the notched washer; Assemble the base (E) to the supports (F) by fastening the three self-threading screws.

Screw the "PAR" bulb into the lower bulb-holder.

Slide the diffuser (A) through the metal stem (B).

Insert the diffuser (A) into the metal structure (B) and through the openings in the supports (C). Utilize the tip of a screwdriver to help your self if necessary to align the holes in the diffuser to correspond with those present on the support.

Assemble the diffuser (A) by fastening screws (E).(Fig.1 page 15)