


Qbini LED GE


141011XX_141012XX_141021XX_141022XX_141031XX_141032XX_141041XX_141042XX_141111XX_141112XX_141121XX_141122XX_141131XX_141132XX_141141XX_141142XX_141211XX_141212XX_141221XX_141222XX_141231XX_141232XX_141241XX_141242XX_141311XX_141312XX_141321XX_141322XX_141331XX_141332XX_141341XX_141342XX_141411XX_141412XX_141421XX_141422XX_141431XX_141432XX_141441XX_141442XX_141511XX_141512XX_141521XX_141522XX_141531XX_141532XX_141541XX_141542XX_141601XX_141605XX_141604XX_141608XX_141607XX_141606XX_141603XX_114800XX_114803XX_114801XX_114804XX_114802XX_114805XX_114700XX_114701XX_114702XX_114703XX_114704XX_114705XX_114706XX_114707XX

QBINI LED GE




IP 55

QBINI ASY LED GE




IP 55

QBINI ADJUSTABLE LED GE




IP 20

QBINI LED WARM DIM GE




IP 55

QBINI ASY LED WARM DIM GE




IP 55

QBINI ADJUSTABLE LED WARM DIM GE




IP 20

QBINI GENERAL DOWNLIGHT 2x LED



IP 55

QBINI GENERAL DOWNLIGHT 4x LED



IP 55

ELECTRICAL SPECS LED-FIXTURE

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	7,5	9,5	3,0
500	7,5	9,5	4,3

⊕ RED ⊖ BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.

WARM DIM ELECTRICAL SPECS LED-FIXTURE

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
250	15,5	18,5	4

⊕ RED ⊖ BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.

ELECTRICAL SPECS LED-FIXTURE

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	11,9	12,2	4,2
500	11,9	12,2	6

⊕ RED ⊖ BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.

ELECTRICAL SPECS LED-FIXTURE

Drive Current (mA)	Forward Voltage		Power (W)
	min (Vf)	max (Vf)	
350	23,8	24,4	8,4
500	23,8	24,4	12

⊕ RED ⊖ BLACK

For serial connection, respect polarity!
Not suited for connection to mains voltage.
Combine with a Modular LED-driver.



PREVENTING ELECTROSTATIC DAMAGE

A discharge of static electricity may damage sensitive components. Therefore do not touch the LED nor the stripped parts of the wires with bare hands. Always be properly insulated by using ESD gloves.



LIGHT SOURCE - DO NOT TOUCH LED

Touching the LED can result in permanent damage of the light source. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

DRIVERS & ACCESSORIES

For latest version of driver matrix and available accessories check www.supermodular.com or connect with your sales contact.